TE0701 CPLD

Table of contents

- 1 Table of contents
 - o 1.1 Overview
 - 1.1.1 Feature Summary
 - 1.1.2 Firmware Revision and supported PCB Revision
 - 1.2 Product Specification
 - 1.2.1 Port Description
 - 1.2.2 Functional Description
 - 1.2.2.1 JTAG
 - 1.2.2.2 Power
 - 1.2.2.3 VADJ
 - o 1.2.2.3.1 VADJ on PCB REV06+ S4 Control
 - o 1.2.2.3.2 VADJ on PCB REV05- S3 Control
 - ° 1.2.2.3.3 VADJ on I2C Control
 - 1.2.2.4 Reset
 - 1.2.2.5 Boot Mode
 - 1.2.2.6 FMC I2C
 - 1.2.2.7 RGPIO
 - 1.2.2.8 LED
 - 1.2.2.9 UART
 - o 1.3 Appx. A: Change History
 - 1.3.1 Revision Changes
 - 1.3.2 Document Change History
 - ° 1.4 Appx. B: Legal Notices
 - 1.4.1 Data Privacy
 - 1.4.2 Document Warranty
 - 1.4.3 Limitation of Liability
 - 1.4.4 Copyright Notice
 - 1.4.5 Technology Licenses
 - 1.4.6 Environmental Protection
 - 1.4.7 REACH, RoHS and WEEE

Overview

CPLD Device with designator U14: LCMX02-1200HC

Feature Summary

- Power Management
 - VADJ Configuration via DIP-Switch or I2C
- Reset Management
- Boot Mode Controller
- FPGA UART routingRGPIO Interface to FPGA

Firmware Revision and supported PCB Revision

See Document Change History

Product Specification

Port Description

Name / opt. VHD Name	Direction	Pin	Description			
ACBUS4		96	FTDI / currently_not_used			
ACBUS5		88	FTDI / currently_not_used			
ADBUS4	out	98	constant 0 / currently_not_used			
ADBUS7	in	97	/ currently_not_used			
BDBUS0	in	87	UART TX from FTDI			
BDBUS1	out	86	UART RX to FTDI			
C_TCK	out	81	JTAG FTDI			
C_TDI	out	84	JTAG FTDI			
C_TDO	in	83	JTAG FTDI			
C_TMS	out	85	JTAG FTDI			
СМО	in	99	DIP Switch S3-M1			
CM1	in	1	ritch S3-M2			
CM2	in	51	REV06+ only: DIP Switch S4-4 / RGPIO Bus (powered by VIOTB (FMC VADJ))			
EN_FMC	out	31	J and 3V3V_FMC Power on			
EN1	out	24	wer Enable Pin for Module CPLD			
FMC_PRSNT	in	28	MC Card present pin (zero if not present)			
FMC_SCL	out	10	MC I2C			
FMC_SDA	inout	8	MC I2C			
FMC_TCK	out	4	TAG FMC / currently_not_used			
FMC_TDI	out	12	TAG FMC / currently_not_used			
FMC_TDO	in	9	JTAG FMC / currently_not_used			
FMC_TMS	out	7	JTAG FMC / currently_not_used			
HDMI_SCL	inout	47	HDMI / used also for I2C FMC control			
HDMI_SDA	inout	45	HDMI / used also for I2C FMC control			
HDMI_SPDIF	out	15	HDMI / currently_not_used			
HDMI_SPDIFOUT	in	14	HDMI / currently_not_used			
JTAGEN		82	Enable JTAG access to carrier CPLD for Firmware update (zero: JTAG routed to module, one: CPLD access)			
			Set DIP Switch S3-JTAGEN to ON, for module access.			
M_TCK	in	91	JTAG Module			
M_TDI	in	94	JTAG Module			
M_TDO	out	95	JTAG Module			
M_TMS	in	90	JTAG Module			
MIO10	inout	29	MIO			
MIO11	inout	19	MIO			
MIO12	inout	36	MIO			

MIO13	inout	30	MIO		
MIO14	inout	37	MIO / Module UART0.RX << BDBUS0		
MIO15	in	18	MIO / Module UART0.TX >> BDBUS1		
MODE	out	27	oot Mode for Zynq Devices (Flash or SD)		
NOSEQ	inout	21	No Sequence, connected to Module CPLD / currently_not_used		
PG_C2M	out	20	Power Good for FMC		
PGOOD	inout	25	onnected to Module CPLD / currently_not_used		
PHY_LED1	out	42	Y LED		
PHY_LED2	out	43	PHY LED		
POK_FMC	in	32	FMC Power good from FMC VADJ DCDC		
PX6	inout	49	PMOD J2		
PX7	inout	48	PMOD J2		
RESIN	out	13	Module Reset		
REVISION_DETECION	in	57	REV06+ only: Detection / currently_not_used		
S1	in	3	User Pushbutton		
S2	in	2	User Pushbutton / global Reset		
SD_DETECT	in	40	SD Detection		
SD_WP	in	41			
SEL_SD	out	39	Selection, MMC SD Slot or PMOD J2		
ULED1	out	78	ED D1		
ULED2	out	77	LED D2		
ULED3	out	76	LED D3		
ULED4	out	16	LED D4		
ULED5	out	69	LED D5, powered by VIOTB (FMC VADJ)		
ULED6	out	68	ED D6, powered by VIOTB (FMC VADJ)		
ULED7	out	65	LED D7, powered by VIOTB (FMC VADJ)		
ULED8	out	64	LED D8, powered by VIOTB (FMC VADJ)		
USB_OC	in	17	USB Over Current		
VID0	out	34	VADJ Voltage selection (EN5335QI)		
VID1	out	35	VADJ Voltage selection (EN5335QI)		
VID2	out	38	VADJ Voltage selection (EN5335QI)		
X6	in	60	Module IO (powered by VIOTB (FMC VADJ))		
Y0	in	75	I2C SCL (powered by VIOTB (FMC VADJ))		
Y1	out	66	I2C SDA_OUT (powered by VIOTB (FMC VADJ))		
Y2	in	67	RGPIO CLK (powered by VIOTB (FMC VADJ))		
Y3	out	70	RGPIO TX (powered by VIOTB (FMC VADJ))		
Y4	in	74	RGPIO RX (powered by VIOTB (FMC VADJ))		
Y5	in	71	I2C SDA_IN (powered by VIOTB (FMC VADJ))		
Y6	in	63	Module IO (powered by VIOTB (FMC VADJ))		

Functional Description

JTAG

JTAGEN set carrier board CPLD into the chain for firmware update. In normal mode JTAG is routed directly to Module. Set S3-ENJTAG to OFF to get access to carrier CPLD.

FMC JTAG is currently not enabled.

Power

EN1 is set to logical one .

EN_FMC is set to logical one or is controlled by I2C on I2C Mode.

PG_C2M is set to logical one or is controlled by I2C on I2C Mode.

VADJ

VADJ on PCB REV06+ S4 Control

This mode is only available on PCB Revision 06 or higher.

S4 control will be enabled on power on sequence or reset (S2-Button), if one of the three S4-DIP switches is set to one.

In this Mode I2C-controll is not selectable and S3-M1 and S3-M2 are available as User-DIP-Switch.

S4-3(VID2)	S4-2(VID1)	S4-1(VID0)	Description
ON	ON	ON	VADJ: 3.3V
ON	ON	OFF	VADJ: 2.5V
ON	OFF	ON	VADJ: 1.8V
ON	OFF	OFF	VADJ: 1.5V
OFF	ON	ON	VADJ: 1.25V
OFF	ON	OFF	VADJ: 1.2V
OFF	OFF	ON	VADJ: 0.8V (Do not use, not supported as IO standard)
OFF	OFF	OFF	used to set VADJ control to REV05- or I2C control after power up sequence

VADJ on PCB REV05- S3 Control

S4 control will be disabled on power on sequence or reset (S2-Button), if all of the three S4-DIP switches is set to OFF or older PCB revision is used.



Do not set S4-Switches to ON, if REV05- or I2C control is enabled.

S3-M1	S3-M2	Description	
OFF	OFF	VADJ: 1.8V	
OFF	ON	VADJ: 2.5V	
ON	OFF	VADJ: 3.3V	
On	ON	I2C controlled	

VADJ on I2C Control

Disable S4 Control (see VADJ on PCB REV05- S3 Control) and set S3-M1 and S3-M2 to on. I2C VADJ Control use TE0701 HDMI I2C Bus (HDMI_SCL and HDMI_SDA) connected to module FPGA PL side. I2C-GPIO controller device address is 0x22. Transmitted data will be converted to a 8-bit GPIO bus.

Bit	Access	Default	Description
7	R/W	0	FMC - Enable
6	R/W	0	VID2
5	R/W	0	VID1
4	R/W	0	VID0
3	R/W	0	PG_C2M - Enable
2	R	x	POK_FMC (EN5335QI Power OK)
1	R	x	one: I2C Mode, zero: DIP Mode,
0	R	x	VID Mode (zero: S4-DIP-controlled, one: REV05-/I2C controlled)

VID2	VID1	VID0	Description
0	0	0	VADJ: 3.3V
0	0	1	VADJ: 2.5V
0	1	0	VADJ: 1.8V
0	1	1	VADJ: 1.5V
1	0	0	VADJ: 1.25V
1	0	1	VADJ: 1.2V
1	1	0	VADJ: 0.8V
1	1	1	reserved

To read I2C with petalinux use i2cget -y 0 0x22.

- -y: do not confirm input
- 0: I2CBUS, use bus number, which is connected to TE0701 HDMI I2C Bus (HDMI_SCL and HDMI_SDA)
 0x22 I2C GPIO controller on TE0701 CPLD

To write I2C with petalinux use i2cset -y 0 0x22 0x80

- -y: do not confirm input
- 0: I2CBUS, use bus number, which is connected to TE0701 HDMI I2C Bus (HDMI_SCL and HDMI_SDA)
 0x22 I2C GPIO controller on TE0701 CPLD
- 0x80: Enable FMC Power with VAD 3.3V, see I2C control table.

Reset

RESIN (negative Reset) to module, can be set by S2 button.

Boot Mode

Boot mode is set to SD-Boot, when SD-Card is detected.

FMC I2C

"3 wire split i2c" to to normal I2C:

```
FMC_SDA <= '0' when Y5='0' else 'Z';
FMC_SCL <= Y0 and PON;
Y1 <= FMC_SDA;
```

RGPIO

RGPIO Master is a 32Bit Remote GPIO Interface to talk with FPGA over 3 lanes.

RGPIO Pin to FPGA	Value
0	MIO10
1	MIO11
2	MIO12
3	MIO13
4	MIO14
5	MIO15
6	PX6
7	PX7
8	S1
9	СМО
10	CM1
11	CM2
12	SD_WP
13	SD_DETECT
14	USB_OC
15	POK_FMC
16	FMC_PRSNT
17	PGOOD
18	NOSEQ
19	unused
20	X6
21	Y6
22-23	unused
24-27	reserved
28-31	Interface detection

RGPIO Pin from FPAG	Value
0-7	LED 1-8
8-9	PHY_LED 1/2
10-23	unused
24-27	reserved
28-31	Interface detection

LED

LED	Description
ULED1	VADJ selection when RGPIO Bus is not active else RGPIO Bus Pin 0
	VADJ selection: blink when VCCIO(VIOTB/VADJ) is disabled else on when VADJ on PCB REV05- or I2C Control or off when VADJ on PCB REV06+ S4 Control
ULED2	I2C control mode when RGPIO Bus is not active else RGPIO Bus Pin 1
ULED3	UART to Module activity when RGPIO Bus is not active else RGPIO Bus Pin 2
ULED4	UART to FTDI activity when RGPIO Bus is not active else RGPIO Bus Pin 3
ULED5	BOOTMODE (on Flash, off SD) when RGPIO Bus is not active else RGPIO Bus Pin 4
ULED6	CM2 when RGPIO Bus is not active else RGPIO Bus Pin 5
ULED7	X6 when RGPIO Bus is not active else RGPIO Bus Pin 6
ULED8	Y6 when RGPIO Bus is not active else RGPIO Bus Pin 7

PHY LED	Description
PHY_LED1	Y2 when RGPIO Bus is not active else RGPIO Bus Pin 8
PHY_LED2	Y4 when RGPIO Bus is not active else RGPIO Bus Pin 9

UART

То	From	Description
MIO14	BDBUS0	Module UART0.RX
BDBUS1	MIO15	Module UART0.TX

Appx. A: Change History

Revision Changes

Older Revisions to REV05

• Power Management

- o three VADJ Control Modi (REV06+ S4 Control, REV05- S3 Control and I2C Control)
- Reset Management
 only little changes
 RGPIO Interface to FPGA
 RGPIO support
- LED
- o new Order and accessible by RGPIO

Document Change History

To get content of older revision got to "Change History" of this page and select older document revision number.

Date	Document Revision	CPLD Firmware Revision	Supported PCB Revision	Authors	Description
		REV05	REV03,REV04, REV05,REV6		Add FMC I2C description
	Error rendering macro 'page-info'			Error	
				render	
	Ambiguous method overloading for			ing	
	method jdk.			macro	
	proxy279.\$Proxy4022#hasContentLevel				
	Permission. Cannot resolve which			'page-	
	method to invoke for [null, class java.			info'	
	lang.String, class com.atlassian.			Ambig	
	confluence.pages.Page] due to			uous	
	overlapping prototypes between:			metho	
	[interface com.atlassian.confluence.user.			d	
	ConfluenceUser, class java.lang.String,			overlo	
	class com.atlassian.confluence.core.			ading	
	ContentEntityObject] [interface com.			for	
	atlassian.user.User, class java.lang.			metho	
	String, class com.atlassian.confluence.			d jdk.	
	core.ContentEntityObject]			proxy2	
				79.\$Pr	
	Unknown macro: 'metadata	,		oxy402	
	Onknown macro: metadata			2#has	
				Conten	
				tLevel	
				Permis	
				sion.	
				Cannot	
				resolve	
				which	
				metho	

Error rendering macro 'page-info'

Ambiguous method overloading for method jdk. proxy279.\$Proxy4022#h asContentLevelPermissi on. Cannot resolve which method to invoke for [null, class java.lang. String, class com. atlassian.confluence. pages.Page] due to overlapping prototypes between: [interface com. atlassian.confluence. user.ConfluenceUser, class java.lang.String, class com.atlassian. confluence.core. ContentEntityObject] [interface com.atlassian. user.User, class java. lang.String, class com. atlassian.confluence. core.

ContentEntityObject]

d to invoke for [null, class java. lang. String, class com. atlassi an. conflue nce. pages. Page] due to overla pping prototy pes betwee n: [interfa се com. atlassi an. conflue nce. user. Conflu enceU ser. class java. lang. String,

class

				com.	
				atlassi	
				an.	
				conflue	
				nce.	
				core.	
				Conten	
				tEntity	
				Object]	
				[interfa	
				ce	
				com.	
				atlassi	
				an.	
				user.	
				User,	
				class	
				java.	
				lang.	
				String,	
				class	
				com.	
				atlassi	
				an.	
				conflue	
				nce.	
				core.	
				Conten	
				tEntity	
				Object]	
				<u> </u>	
2017-08-14	v.27	REV05	REV03,REV04, REV05,REV6	John Hartfiel	Description correction on port table
2017-06-08	v.26	REV05	REV03,REV04, REV05,REV6		document style update.
2016-11-29	v.24	REV05	REV03,REV04, REV05,REV6	John Hartfiel	Revision 05 finished
2016-04-11	v.1				Initial release
	I		I	II	

Error render ing macro 'pageinfo' Ambig uous metho d overlo ading for metho d jdk. proxy2 79.\$Pr oxy402 2#has Conten tLevel Permis sion. Cannot resolve which metho d to invoke for [null, class java. lang. String, class com. atlassi an.

		conflue	
		nce.	
		pages.	
		Page]	
		due to	
		overla	
		pping	
		prototy	
		pes	
		betwee	
		n:	
		[interfa	
		ce	
		com.	
		atlassi	
		an.	
		conflue	
		nce.	
		user.	
		Conflu	
		enceU	
		ser,	
		class	
		java.	
		lang.	
		String,	
		class	
		com.	
		atlassi	
		an.	
		conflue	
		nce.	
		core.	
		Conten	
		tEntity	
		Object]	
		[interfa	
		ce	
		com.	

			atlassi	
			an.	
			user.	
			User,	
			class	
			java.	
			lang.	
			String,	
			class	
			com.	
			atlassi	
			an.	
			conflue	
			nce.	
			core.	
			Conten	
			tEntity	
			Object]	
			, .	
				J
	All			
	7.11			1
			Error	
			render	
			ing	
			macro	
			'page-	
			info'	
			Ambig	
			uous	
			metho	
			d	
			overlo	
			ading	
			for	
			metho	
			d idk.	
			d jdk. proxv2	
			d jdk. proxy2	

79.\$Pr oxy402 2#has Conten tLevel Permis sion. Cannot resolve which metho d to invoke for [null, class java. lang. String, class com. atlassi an. conflue nce. pages. Page] due to overla pping prototy pes betwee n: [interfa се com. atlassi

		conflue
		nce.
		user.
		Conflu
		enceU
		ser,
		class
		java.
		lang.
		String,
		class
		com.
		atlassi
		an.
		conflue
		nce.
		core.
		Conten
		tEntity
		Object]
		[interfa
		ce
		com.
		atlassi
		an.
		user.
		User,
		class
		java.
		lang.
		String,
		class
		com.
		atlassi
		an.
		conflue
		nce.
		core.
		Conten

1			ı
		tEntity	
		Object]	

Appx. B: Legal Notices

Data Privacy

Please also note our data protection declaration at https://www.trenz-electronic.de/en/Data-protection-Privacy

Document Warranty

The material contained in this document is provided "as is" and is subject to being changed at any time without notice. Trenz Electronic does not warrant the accuracy and completeness of the materials in this document. Further, to the maximum extent permitted by applicable law, Trenz Electronic disclaims all warranties, either express or implied, with regard to this document and any information contained herein, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non infringement of intellectual property. Trenz Electronic shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein.

Limitation of Liability

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

Copyright Notice

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

Technology Licenses

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

Environmental Protection

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.

REACH, RoHS and WEEE

REACH

Trenz Electronic is a manufacturer and a distributor of electronic products. It is therefore a so called downstream user in the sense of REACH. The products we supply to you are solely non-chemical products (goods). Moreover and under normal and reasonably foreseeable circumstances of application, the goods supplied to you shall not release any substance. For that, Trenz Electronic is obliged to neither register nor to provide safety data sheet. According to present knowledge and to best of our knowledge, no SVHC (Substances of Very High Concern) on the Candidate List are contained in our products. Furthermore, we will immediately and unsolicited inform our customers in compliance with REACH - Article 33 if any substance present in our goods (above a concentration of 0,1 % weight by weight) will be classified as SVHC by the European Chemicals Agency (ECHA).

RoHS

Trenz Electronic GmbH herewith declares that all its products are developed, manufactured and distributed RoHS compliant.

WFFF

Information for users within the European Union in accordance with Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

Users of electrical and electronic equipment in private households are required not to dispose of waste electrical and electronic equipment as unsorted municipal waste and to collect such waste electrical and electronic equipment separately. By the 13 August 2005, Member States shall have ensured that systems are set up allowing final holders and distributors to return waste electrical and electronic equipment at least free of charge. Member States shall ensure the availability and accessibility of the necessary collection facilities. Separate collection is the precondition to ensure specific treatment and recycling of waste electrical and electronic equipment and is necessary to achieve the chosen level of protection of human health and the environment in the European Union. Consumers have to actively contribute to the success of such collection and the return of waste electrical and electronic equipment. Presence of hazardous substances in electrical and electronic equipment results in potential effects on the environment and human health. The symbol consisting of the crossed-out wheeled bin indicates separate collection for waste electrical and electronic equipment.

Trenz Electronic is registered under WEEE-Reg.-Nr. DE97922676.

Error rendering macro 'page-info'

Ambiguous method overloading for method jdk.proxy279.\$Proxy4022#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com. atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]