# **TEC0850 MAX10 Firmware**

### Table of contents

- Table of contents
- CPLD Access
- Available CPLD Firmware
- Available CFLD Finnware
   General instructions

   MAX 10 Firmware Update General Requirements
   MAX 10 Firmware Update General Procedure

## **CPLD** Access

(i) Remove TEC0850 from Backplane

- Set DIP S1:1 to OFF
- Connect 12V Power source



Connect Arrow USB Programmer



#### Available CPLD Firmware

Firmware description

 TEC0850 MAX10 - SMB Firmware

#### General instructions

#### MAX 10 Firmware Update - General Requirements

- Quartus Prime software, available for free (lite version) on https://www.intel.de/
- Arrow USB Programmer Driver
   Quartus compatible, ITAC program
- Quartus compatible JTAG programmer, for example:
  - TEI0004 Arrow USB Programmer2 or carrier board with FTDI for JTAG
     Other JTAG Programmer compatible with Quartus Programmer
- JTAG must be connected to FPGA JTAG
- Correct Firmware (\*.pof file) from Download area

#### MAX 10 Firmware Update - General Procedure

#### Important:

- Connect only one JTAG device to host PC.
- Close all other JTAG programs.

#### Procedure:

- 1. Enable FPGA JTAG access (see JTAG section on Firmware description)
- 2. Connect JTAG
- 3. Power on system
- 4. Open Quartus Prime
- 5. Open Quartus Programmer from top menu: Tools Programmer
- 6. Select from Programmer top menu: Edit Hardware Setup
- 7. Select via the drop down menu: Arrow-USB-Blaster [USB0] (Installation of Arrow USB Programmer needed) and close the window
- 8. Click Add File ...
- 9. Select correct Firmware from Download area and press Open
- 10. Click Start to program the device

Programmer - [Chain1.cdf]*														×	
Eile Edit View Processing Tools Window Help Search Intel FPGA															
Arrow-USB-Blaster [USB0]								Mode: JTAG   Progress:							
Enable real-time	Enable real-time ISP to allow background programming when available														
▶ <sup>™</sup> Start	File	Device	Checksum	Usercode	Program/ Configure	Verify	Blank- Check	Examine	Security Bit	Erase	ISP CLAMP	IPS File	EKP File		
Stop	S:/firmware.pof CFM0	10M085AU169	01DE4027	005BEA2C	✓ ✓										
Auto Detect	UFM				✓										
Add File															
Change File															
Save File															
Add Device															
La Down															
	TDO	NU169													
L	J [														

More information are available on the Firmware description.