

# TEB0728 TRM

[Download PDF version of this document.](#)

## Table of Contents

- [Overview](#)
  - [Key Features](#)
  - [Block Diagram](#)
  - [Main Components](#)
  - [Initial Delivery State](#)
  - [Configuration Signals](#)
- [Signals, Interfaces and Pins](#)
  - [Board to Board \(B2B\) I/Os](#)
  - [On-board Connector](#)
  - [JTAG Interface Base](#)
  - [SD Card Socket](#)
  - [RJ45 Connector](#)
- [On-board Peripherals](#)
  - [Push button](#)
  - [Jumpers](#)
  - [LEDs](#)
- [Power and Power-On Sequence](#)
  - [Power Supply](#)
  - [Power Rails](#)
- [Board to Board Connectors](#)
  - [Connector Mating height](#)
  - [Connector Speed Ratings](#)
  - [Current Rating](#)
  - [Connector Mechanical Ratings](#)
  - [Manufacturer Documentation](#)
  - [Absolute Maximum Ratings](#)
  - [Recommended Operating Conditions](#)
  - [Physical Dimensions](#)
- [Currently Offered Variants](#)
- [Revision History](#)
  - [Hardware Revision History](#)
  - [Document Change History](#)
- [Disclaimer](#)
  - [Data Privacy](#)
  - [Document Warranty](#)
  - [Limitation of Liability](#)
  - [Copyright Notice](#)
  - [Technology Licenses](#)
  - [Environmental Protection](#)
  - [REACH, RoHS and WEEE](#)

## Overview

The Trenz Electronic TEB0728 Carrier Board provides functionalities for testing, evaluation and development purposes of company's 6 x 6 cm SoMs. The Carrier Board is equipped with various components and connectors for different configuration setups. See "[6 x 6 SoM](#)" Carriers" page for more information about 6 x 6 cm SoMs.


Refer to <http://trenz.org/TEB0728-info> for the current online version of this manual and other available documentation.

## Key Features

- Samtec Tiger Eye Terminal Socket ( 80 pins, 2 rows)
- Micro SD card socket


- 3 User LEDs, Red, Yellow, Green
- Two RJ45 Gigabit Ethernet socket
- Trenz 6x6 module connector strips (3 x Samtec Tiger Eye series connectors)
- Barrel Jack for 5V power supply
- One user push button

## Block Diagram



TEB0728 block diagram

## Main Components



**TEB0728 main components**

1. User push-button, S1
2. Jumper (Boot Mode), J4
3. External connector (VG96) placeholder, J5 / J6
4. LEDs , D1
5. SD Card Connector, J10
6. Board to Board Connector, J1-J2-J3
7. RJ45 Gigabit Ethernet connector, J7-J8
8. XMOD JTAG- / UART-header, JB1
9. Barrel jack for 5V power supply, J9
10. Jumper(VCCIO\_13), J11
11. CR1220 Backup-Battery holder, B1

## Initial Delivery State

There is no hardware component to be programmed on the carrier.

| Storage device name | Content | Notes |
|---------------------|---------|-------|
| ---                 | ---     | ---   |

Initial delivery state of programmable devices on the module

## Configuration Signals

| Signal | Designator | B2B   | Jumper | Boot Mode |
|--------|------------|-------|--------|-----------|
| Boot_R | J4         | J2-11 | Open   | QSPI      |
|        |            |       | Short  | SD Card   |

Boot process.

There is a user push button which is used for RESET signal.

| Signal                  | Designator | B2B  | Active Level |
|-------------------------|------------|------|--------------|
| Reset process.<br>RESET | S1         | J2-7 | Active High  |

## Signals, Interfaces and Pins

### Board to Board (B2B) I/Os

Number of I/O signals FPGA bank numbers connected to the B2B connectors:

| B2B Connector | Interfaces          | Number of I/O                    | Notes                                                                            |
|---------------|---------------------|----------------------------------|----------------------------------------------------------------------------------|
| J1            | User I/O            | 48 singel ended, 24 differential | Connected to Bank 13                                                             |
|               |                     | 4 Single ended                   | MIO10...13                                                                       |
|               | CANH , CANL         | 2 single ended                   | MIO8, MIO9                                                                       |
| J2            | User I/O            | 22 singel ended, 11 differential |                                                                                  |
|               |                     | 38 single ended                  | MIO16...53                                                                       |
|               | SoM Control Signals | 5                                | RESET, RST_OUT, BOOT_R,                                                          |
|               | JTAG Interface      | 4                                | TCK , TDO, TDI, TMS                                                              |
| J3            | User I/O            | 20 Single ended, 10 differential | Connected to Bank 35                                                             |
|               |                     | 34 single ended, 17 differential | Connected to Bankd 33                                                            |
|               | Ethernet 1          | 4 single ended, 2 differential   | ETH_CTREF , ETH_TD+ , ETH_TD- , ETH_RD+ , ETH_RD- , ETH_LED1, ETH_LED2, ETH_LED3 |
|               | Ethernet 2          | 4 single ended, 2 differential   | ETH_CTREF , ETH_TD+ , ETH_TD- , ETH_RD+ , ETH_RD- , ETH_LED1, ETH_LED2, ETH_LED3 |

General overview of PL I/O signals and SoM's interfaces connected to the B2B connectors.

### On-board Connector

There are two pin placeholder on the board, J5-J6.

| VGA96 Vertical Connector | Interfaces          | Number of I/O                    | Notes                       |
|--------------------------|---------------------|----------------------------------|-----------------------------|
| J5                       | User I/O            | 48 singel ended, 24 differential | Connected to Bank 13        |
|                          |                     | 34 single ended, 17 differential | Connected to Bank 33        |
| J6                       | User I/O            | 42 singel ended, 21 differential |                             |
|                          |                     | 27 single ended                  | MIO16... MIO39 + MIO51...53 |
|                          |                     | 4 single ended                   | MIO10...13                  |
|                          | SoM Control Signals | 3                                | RESET, RST_OUT, BOOT_R      |
|                          | JTAG Interface      | 4                                | TCK , TDO, TDI, TMS         |
|                          | CANH , CANL         | 2 single ended                   | MIO8, MIO9                  |

General information about On-board connectors information

## JTAG Interface Base

JTAG access to the TEB0728 Trenz module is available through B2B connector J2. JTAG Programmer TE0790\_02 is provided by Trenz Electronic, More information is available [here](#).

| Designator | B2B Pin | XMOD Header JB1 | Note                                                      |
|------------|---------|-----------------|-----------------------------------------------------------|
| A          | J2-15   | JB1-3           | UART Txd - input                                          |
| B          | J2-16   | JB1-7           | UART Rxd - Output                                         |
| C          | J2-12   | JB1-4           | JTAG-TMS                                                  |
| D          | J2-10   | JB1-8           | JTAG-TDI                                                  |
| F          | J2-8    | JB1-10          | JTAG-TDO                                                  |
| H          | J2-6    | JB1-12          | JTAG-TCK                                                  |
| G          | J2-7    | JB1-11          | RESET will be connected to Push Button on JTAG Programmer |
| 3.3V       | -       | JB1-5           | connected to GND                                          |
| VIO        | J2-2/4  | JB1-6           | VIO is connected to 3.3V which is supplied by carrier     |

JTAG interface Base

## SD Card Socket

Power supply voltage for SD card holder is 3.3V.

| Signals | B2B   | Notes |
|---------|-------|-------|
| CMD     | J2-29 |       |
| CLK     | J2-34 |       |
| DAT0    | J2-37 |       |
| DAT1    | J2-40 |       |
| DAT2    | J2-32 |       |
| CD/DAT3 | J2-31 |       |

|    |       |  |
|----|-------|--|
| CD | J2-35 |  |
| WP | J2-33 |  |

#### On board peripherals

## RJ45 Connector

Both Ethernet sockets,ETH1 and ETH2, are connected to the Board to Board (B2B) J3 on the carrier.

| Signal    | ETH1  | ETH2  | Notes                |
|-----------|-------|-------|----------------------|
| ETH_TD+   | J3-58 | J3-28 | Transfer             |
| ETH_TD-   | J3-56 | J3-26 |                      |
| ETH_RD+   | J3_52 | J3-22 | Receive              |
| ETH_RD-   | J3-50 | J3-20 |                      |
| ETH_CTREF | J3_57 | J3-25 |                      |
| ETH_LED1  | J3-55 | J3-23 | Yellow LED- Activity |
| ETH_LED3  | J3-51 | J3-19 | Green Green- Link    |

#### Ethernet Connections to B2B Connectors

## On-board Peripherals

## Push button

| Designator | Connected to | B2B  | Active Level | Note                |
|------------|--------------|------|--------------|---------------------|
| S1-A       | RESET        | J2-7 | Active high  | General Input RESET |

#### On-board push button

## Jumpers

| Designator | Connected to | B2B   | Note           |
|------------|--------------|-------|----------------|
| J4         | Boot_R       | J2-11 | Open: QSPI     |
|            |              |       | Short: SD Card |

#### On-board Jumpers

| Designator | Connected to | Voltage | Note                                   |
|------------|--------------|---------|----------------------------------------|
| J11        | VCCIO_13     | 3.3 V   | Pin 1 and the middle pin are connected |
|            |              | 1.8 V   | Pin 3 and the middle pin are connected |

#### On-board Jumpers

## LEDs

| Designator | Color  | B2B   | Active Level | Note |
|------------|--------|-------|--------------|------|
| D1-A       | Red    | J2-30 | Active high  |      |
| D1-B       | Yellow | J2-38 | Active high  |      |
| D1-C       | Green  | J2-36 | Active high  |      |

#### On-board LEDs


## Power and Power-On Sequence

### Power Supply


No power supply protection circuit on the carrier, module will be powered directly

Single 5V power supply with minimum current capability of 2.5A is recommended to operate the board.

- 5V VIN (inner)
- GND (outer)



Power Connector

### Power Consumption

| Power Input Pin | Typical Current |
|-----------------|-----------------|
| VIN             | TBD*            |
| VBATT           | TBD*            |

#### Power Consumption

\* TBD - To Be Determined

### Power Rails

| Module Connector (B2B) Designator | VCC / VCCIO | Direction | Pins | Notes                            |
|-----------------------------------|-------------|-----------|------|----------------------------------|
| JB1                               | VIN         | Output    | 1, 3 | Up to 12V carrier supply voltage |
|                                   | 3.3V        | Input     | 19   | PL IO-bank VCCIO                 |
|                                   | VCCO_13     | Output    | 39   | 1.8V or 3.3V over jumper         |
| JB2                               | 3.3V        | Input     | 2, 4 | 3.3V module supply voltage       |
|                                   | 1.8V        | Input     | 5    | PL IO-bank VCCIO                 |
|                                   | VBATT       | Output    | 1    | RTC buffer voltage               |
| JB3                               | -           | -         | -    | -                                |

**Carrier Power Rails.**

## Board to Board Connectors

6 x 6 modules use two or three [Samtec Micro Tiger Eye Socket Strip](#) on the bottom side.

- 3 x REF-189018-01 (compatible to TEM-140-02-03.0-H-D-A ), (80 pins, "40" per row)

| Connector Specifications    | Value                          |
|-----------------------------|--------------------------------|
| Insulator material          | Black Liquid Crystal Polymer   |
| Stacking height             | 6 mm                           |
| Contact material            | Phosphor-bronze                |
| Plating                     | Au or Sn over 50 " (1.27 m) Ni |
| Current rating              | 2.9 A per pin (2 pins powered) |
| Operating temperature range | -55 °C to +125 °C              |
| RoHS compliant              | Yes                            |

**Connector specifications.**

### Connector Mating height

When using the same type on baseboard, the mating height is 6mm. Other mating heights are possible by using connectors with a different height

| Order number | Connector on baseboard | compatible to         | Mating height |
|--------------|------------------------|-----------------------|---------------|
| 26056        | REF-189018-01          | TEM-140-02-03.0-H-D-A | 6 mm          |
|              | SEM-140-02-03.0-H-D-A  | TEM-140-02-03.0-H-D-A | 6 mm          |

**Connectors.**

The module can be manufactured using other connectors upon request.

### Connector Speed Ratings

The LSHM connector speed rating depends on the stacking height; please see the following table:

| Stacking height | Speed rating |
|-----------------|--------------|
|-----------------|--------------|

|                     |          |
|---------------------|----------|
| 6 mm, Single-Ended  | 12 GHz   |
| 10 mm, Differential | 17 GHz   |
| 6 mm, Single-Ended  | 14.5 GHz |
| 10 mm, Differential | 17.5 GHz |

**Speed rating.**

### Current Rating

Current rating of Samtec Micro Tiger Eye Connector™ LSHM B2B connectors is 2.9A per pin (2 adjacent pins powered).

### Connector Mechanical Ratings

- Shock: 100G, 6 ms Sine
- Vibration: 7.5G random, 2 hours per axis, 3 axes total

### Manufacturer Documentation

| File                               | Modified                        |
|------------------------------------|---------------------------------|
| PDF File SEM-140-02-03.0-H-D-A.pdf | 11 02, 2019 by Pedram Babakhani |
| PDF File TEM-140-02-03.0-H-D-A.pdf | 11 02, 2019 by Pedram Babakhani |

[Download All](#)

## Absolute Maximum Ratings

| Parameter           | Min | Max | Units | Note                                                                                                              |
|---------------------|-----|-----|-------|-------------------------------------------------------------------------------------------------------------------|
| VIN supply voltage  | --  | --  | V     | <ul style="list-style-type: none"> <li>• Connected directly to the module power supply, see Module TRM</li> </ul> |
| Storage Temperature | -25 | +85 | °C    |                                                                                                                   |

**Module absolute maximum ratings.**

## Recommended Operating Conditions

Operating temperature range depends also on customer design and cooling solution. Please contact us for options.


| Parameter             | Min | Max | Units | Note                                                                                                                                                              |
|-----------------------|-----|-----|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| VIN supply voltage    | --  | --  | V     | <ul style="list-style-type: none"> <li>• Connected directly to the module power supply, see Module TRM</li> <li>• 5V recommended for usage with TE0728</li> </ul> |
| Operating Temperature | -25 | +85 | °C    |                                                                                                                                                                   |

**Recommended operating conditions.**


## Physical Dimensions

- Module size: 100 mm × 107.7 mm. Please download the assembly diagram for exact numbers.

- Mating height with standard connectors: 7 mm.
- PCB thickness: 1.6 mm.



Physical Dimension



Currently Offered Variants

|                                  |                             |
|----------------------------------|-----------------------------|
| Trenz shop TEB0728 overview page |                             |
| <a href="#">English page</a>     | <a href="#">German page</a> |

Trenz Electronic Shop Overview

Revision History

Hardware Revision History

| Date       | Revision | Changes                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2018-07-18 | 02       | <ul style="list-style-type: none"><li>• changed value R1</li><li>• changed magjack connectors J7, J8</li><li>• changed 2.1mm power jack THT on SMD</li><li>• magjack connectors: pin8 connected to frame (shassis ground)</li><li>• lib component update</li><li>• added thermal bias to mounting holes</li><li>• added visual serial number</li><li>• changed 2.1mm power jack THT on SMD</li><li>• added 2 x 10uF to VIN</li></ul> |

|            |    |                                                     |
|------------|----|-----------------------------------------------------|
| 2016-11-02 | 01 | <ul style="list-style-type: none"><li>---</li></ul> |
|------------|----|-----------------------------------------------------|

Hardware Revision History

Hardware revision number is printed on the PCB board next to the module model number separated by the dash.

Document Change History

| Date                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Revision                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Contributor                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Description                                                                                 |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| <div>Error rendering macro 'page-info'<br/><br/>Ambiguous method overloading for method jdk.proxy279.\$Proxy4022#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]</div> | <div>Error rendering macro 'page-info'<br/><br/>Ambiguous method overloading for method jdk.proxy279.\$Proxy4022#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]</div> | <div>Error rendering macro 'page-info'<br/><br/>Ambiguous method overloading for method jdk.proxy279.\$Proxy4022#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]</div> | <ul style="list-style-type: none"><li>typo table title</li><li>power rail section</li></ul> |
| 2019-6-25                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | v.132                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Pedram Babakhani                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <ul style="list-style-type: none"><li>initial release</li></ul>                             |

|    |     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |      |
|----|-----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| -- | all | <div><div>Error rendering macro 'page-info'</div><div>Ambiguous method overloading for method jdk.proxy279.\$Proxy4022#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]</div></div> | • -- |
|----|-----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|

Document change history.

Disclaimer

Data Privacy

Please also note our data protection declaration at <https://www.trenz-electronic.de/en/Data-protection-Privacy>

Document Warranty

The material contained in this document is provided "as is" and is subject to being changed at any time without notice. Trenz Electronic does not warrant the accuracy and completeness of the materials in this document. Further, to the maximum extent permitted by applicable law, Trenz Electronic disclaims all warranties, either express or implied, with regard to this document and any information contained herein, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non infringement of intellectual property. Trenz Electronic shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein.

Limitation of Liability

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

## Copyright Notice

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

## Technology Licenses

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

## Environmental Protection

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.

## REACH, RoHS and WEEE

### REACH

Trenz Electronic is a manufacturer and a distributor of electronic products. It is therefore a so called downstream user in the sense of [REACH](#). The products we supply to you are solely non-chemical products (goods). Moreover and under normal and reasonably foreseeable circumstances of application, the goods supplied to you shall not release any substance. For that, Trenz Electronic is obliged to neither register nor to provide safety data sheet. According to present knowledge and to best of our knowledge, no [SVHC \(Substances of Very High Concern\) on the Candidate List](#) are contained in our products. Furthermore, we will immediately and unsolicited inform our customers in compliance with REACH - Article 33 if any substance present in our goods (above a concentration of 0,1 % weight by weight) will be classified as SVHC by the [European Chemicals Agency \(ECHA\)](#).

### RoHS

Trenz Electronic GmbH herewith declares that all its products are developed, manufactured and distributed RoHS compliant.

### WEEE

Information for users within the European Union in accordance with Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

Users of electrical and electronic equipment in private households are required not to dispose of waste electrical and electronic equipment as unsorted municipal waste and to collect such waste electrical and electronic equipment separately. By the 13 August 2005, Member States shall have ensured that systems are set up allowing final holders and distributors to return waste electrical and electronic equipment at least free of charge. Member States shall ensure the availability and accessibility of the necessary collection facilities. Separate collection is the precondition to ensure specific treatment and recycling of waste electrical and electronic equipment and is necessary to achieve the chosen level of protection of human health and the environment in the European Union. Consumers have to actively contribute to the success of such collection and the return of waste electrical and electronic equipment. Presence of hazardous substances in electrical and electronic equipment results in potential effects on the environment and human health. The symbol consisting of the crossed-out wheeled bin indicates separate collection for waste electrical and electronic equipment.

Trenz Electronic is registered under WEEE-Reg.-Nr. DE97922676.

Ambiguous method overloading for method `jdk.proxy279.$Proxy4022#hasContentLevelPermission`. Cannot resolve which method to invoke for `[null, class java.lang.String, class com.atlassian.confluence.pages.Page]` due to overlapping prototypes between: `[interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]` `[interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]`