

TE0300 DIP Slide Switch S1 (Configuration)

S1 enables / disables the communication between the Cypress EZ-USB FX2 microcontroller and the I2C CMOS Serial EEPROM.

Turn S1 off when programming the USB EEPROM (storing the USB vendor ID and device ID). This will force the USB microcontroller to provide its default vendor ID and device ID.

S1	Label	position
ON *	EEPROM	EEPROM <u>e</u> nabled
OFF	OFF	EEPROM <u>d</u> isabled

S1 (* default ON)

For further information, please read this [configuration paragraph](#).