

# TE0320 Configuration and User Switches

TE0320 Configuration Switches: settings for USB Firmware, FPGA bitstream programming, Power Supply and reset.