

RESET_FIFO command

This command resets the FIFO of the selected (by Command[1]) endpoint (Command[1] = 2/4/6, all endpoints with the exception of control endpoint for any other value).

Byte	Value	Description
1	0xA4	RESET_FIFO command ID
2	2/4/6/ any other value	Endpoint number any other value means all endpoints with the exception of control endpoint.
From 3 to 64	-	Not used

READ_VERSION Command Packet Layout.

Reply packet doesn't contain any usable information.