

FLASH_WRITE_COMMAND command

This command sends instruction(s) (SPI command(s)) to the SPI Flash. See SPI Flash data sheet for detailed command description. See also [here](#).

Byte	Value	Description
1	0xAA	FLASH_WRITE_COMMAND command ID
2	Write length	Write command length
3	Read length	Read command length
From 4 to write length +3	SPI command(s)	Write SPI command(s)
From write length+4 to 64	-	Not used

FLASH_WRITE_COMMAND Command Packet Layout.

Byte	Description
From 1 to read length	SPI Data Out sequence
From read length +1 to 64	Not used

FLASH_WRITE_COMMAND Reply Packet Layout.