

# TE0300 User Button

The push button is connected to the PB input (pin V16). as detailed in the following table.

| Signal | FPGA pin   | FPGA ball |
|--------|------------|-----------|
| PB     | IP(bank 2) | V16       |

**User button signal details.**

The input is normally low. The input is pulled up when pressed.