

XADC Stops Working

Symptoms: XADC Readings show -273C

This is in most cases related to PS disabling JTAG Access to XADC, this may happen when linux boots as example. This is no malfunction of the Zynq hardware.