

TE0820-REV01_REV02 CPLD

Table of contents

- [1 Table of contents](#)
- [2 Overview](#)
 - [2.1 Feature Summary](#)
 - [2.2 Firmware Revision and supported PCB Revision](#)
- [3 Product Specification](#)
 - [3.1 Port Description](#)
 - [3.2 Functional Description](#)
 - [3.2.1 JTAG](#)
 - [3.2.2 Boot Mode](#)
 - [3.2.3 Power](#)
 - [3.2.4 X0/X1 Pin](#)
- [4 Appx. A: Change History](#)
 - [4.1 Revision Changes](#)
 - [4.2 Document Change History](#)
- [5 Appx. B: Legal Notices](#)
 - [5.1 Data Privacy](#)
 - [5.2 Document Warranty](#)
 - [5.3 Limitation of Liability](#)
 - [5.4 Copyright Notice](#)
 - [5.5 Technology Licenses](#)
 - [5.6 Environmental Protection](#)
 - [5.7 REACH, RoHS and WEEE](#)

Overview

CPLD Device with designator U21: LCMX02-256HC

Feature Summary

- JTAG routing
- Boot Mode settings
- Power/Status Management

Firmware Revision and supported PCB Revision

See Document Change History

Product Specification

Port Description

Name / opt. VHD Name	Direction	Pin	Bank Power	Description
C_TCK	in	30	3.3VIN	JTAG B2B
C_TDI	in	32	3.3VIN	JTAG B2B
C_TDO	out	1	3.3VIN	JTAG B2B

C_TMS	in	29	3.3VIN	JTAG B2B
EN1	in	27	3.3VIN	Power Enable from B2B Connector (Positive Enable) / Used only for PGOOD feedback
ERR_OUT	in	4	1.8V	PS_ERROR_OUT, see ug1085
ERR_STATUS	in	5	1.8V	PS_ERROR_STATUS, see ug1085 / currently_not_used
JTAGEN	in	26	3.3VIN	Enable JTAG access to CPLD for Firmware update (zero: JTAG routed to module, one: CPLD access)
MODE	in	25	3.3VIN	Boot Mode for Zynq/ZynqMP Devices (Flash or SD)
MODE0	out	12	1.8V	ZynqMP Boot Mode Pin 0
MODE1	out	13	1.8V	ZynqMP Boot Mode Pin 1
MODE2	out	14	1.8V	ZynqMP Boot Mode Pin 2
MODE3	out	16	1.8V	ZynqMP Boot Mode Pin 3
NOSEQ	inout	23	3.3VIN	usage CPLD Variant depends
PGOOD	out	28	3.3VIN	Module Power Good.
PHY_LED1	in	17	1.8V	ETH PHY LED1
TCK	out	9	1.8V	JTAG ZynqMP
TDI	out	8	1.8V	JTAG ZynqMP
TDO	in	10	1.8V	JTAG ZynqMP
TMS	out	11	1.8V	JTAG ZynqMP
X0	out	20	VCCO_65	FPGA IO / Firmware Variant
X1	out	21	VCCO_65	FPGA IO / PHY_LED1

Functional Description

JTAG

JTAG signals routed directly through the CPLD to FPGA. Access between CPLD and FPGA can be multiplexed via JTAGEN (logical one for CPLD, logical zero for FPGA) on JM1-89.

Boot Mode

Boot Modes can be selected via B2B Pin Mode. Trenz Electronic provides currently 4 Firmware variants, one for SD/JTAG, one for JTAG/QSPI, one for SD /QSPI and SD/QSPI/JTAG usage.

Mode	JTAG/QSPI-Variant	SD/JTAG-Variant	SD/QSPI (default Firmware)	SD/QSPI/JTAG
low	JTAG	Boot from SD	Boot from SD	JTAG Mode, if NOSEQ* is high otherwise boot from SD
high	Boot from Flash	JTAG	Boot from Flash	JTAG Mode, if NOSEQ* is high otherwise boot from Flash

For other UltraScale+ Boot Modes options custom firmware is needed, see also Table 11.1 Boot Modes from Xilinx UG1085.



A special FSBL is provided on 2017.4 or newer reference designs to write boot image to QSPI with Xilinx tools (Vivado or SDK) on Boot Mode unequal JTAG .



NOSEQ*: Please check the carrier board documentation, before using the SD/QSPI/JTAG firmware variant on TE0820. In the most cases special carrier CPLD firmware is needed.

Power

PGOOD is EN1 and not ER_OUT. There is no additional power management controlled by CPLD.

Internal pullup is used for detection, ER_OUT IO powered by 1.8V. To detect power status, also B2B 1.8V or 3.3V output is usable.

X0/X1 Pin

Pin	Description
X0*	indicate firmware variant and NOSEQ status
X1	PHY_LED1

*It's recommended to forward this signal to a carrier LED if status check is needed.

Firmware Variant	Blink sequence	Condition
QSPI/JTAG	*0000000	if boot mode != JTAG otherwise const. high if NOSEQ='1' or const low if NOSEQ='0'
JTAG/SD	**000000	if boot mode != JTAG otherwise const. high if NOSEQ='1' or const low if NOSEQ='0'
QSPI/SD	****0000/*****	****0000 if NOSEQ='1' or ***** if NOSEQ='0'
SD/QSPI/JTAG	***00000	if boot mode != JTAG otherwise const. high if NOSEQ='1' or const low if NOSEQ='0'

Appx. A: Change History

Revision Changes

- REV02 to REV03
 - new Boot Mode variants
 - new X0 status blink sequencing
- REV01 to REV02
 - Boot Mode variants
 - X1
 - Remove ERR_STATUS

Document Change History

To get content of older revision got to "Change History" of this page and select older document revision number.

Date	Document Revision	CPLD Firmware Revision	Supported PCB Revision	Authors	Description
		REV03	REV02, REV01		

Error rendering macro 'page-info'

Ambiguous method overloading for method jdk.
proxy241.\$Proxy3496#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]

Error rendering macro 'page-info'

Ambiguous method overloading for method jdk.
proxy241.\$Proxy3496#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]



Unknown macro: 'metadata'

Error rendering macro 'page-info'

Ambiguous method overloading for method jdk.
proxy241.\$Proxy3496#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.

- Update Port Table
- Rename page

atlassi
an.
conflu
ence.
pages.
Page]
due to
overla
pping
prototy
pes
betwe
en:
[interfa
ce
com.
atlassi
an.
conflu
ence.
user.
Conflu
enceU
ser,
class
java.
lang.
String,
class
com.
atlassi
an.
conflu
ence.
core.
Conte
ntEntit
yObjec
t]

				[interfa ce com. atlassi an. user. User, class java. lang. String, class com. atlassi an. conflu ence. core. Conte ntEntit yObjec t]	
	v.13	REV03	REV02, REV01		Revision 03 finished
2018-01-10	v.10	REV02	REV02, REV01	John Hartfiel	update description - PHY LED correction
2017-08-21	v.9	REV02	REV02, REV01	John Hartfiel	- Revision 02 finished - small text updates
2017-08-17	v.8	REV02	REV02, REV01	John Hartfiel	- Revision 02 working in process - Boot Mode - X1 output

2017-06-08	v.4	REV01	REV01	John Hartfiel	document style update
2017-03-06	v.2	REV01	REV01	John Hartfiel	Revision 01 finished
2017-03-06	v.1	REV01	REV01	Error rendering macro 'page-info' Ambiguous method overload for method jdk.proxy2 41.\$Proxy34 96#hasContentLevelPermission. Cannot resolve which method to invoke	Initial release

for
[null,
class
java.
lang.
String,
class
com.
atlassi
an.
conflu
ence.
pages.
Page]
due to
overla
pping
prototy
pes
betwe
en:
[interfa
ce
com.
atlassi
an.
conflu
ence.
user.
Conflu
enceU
ser,
class
java.
lang.
String,
class
com.
atlassi

				an. conflu ence. core. Conte ntEntit yObjec t] [interfa ce com. atlassi an. user. User, class java. lang. String, class com. atlassi an. conflu ence. core. Conte ntEntit yObjec t]
	All			

Error
render
ing
macro
'page-
info'

Ambig
uous
metho
d
overlo
ading
for
metho
d jdk.
proxy2
41.\$Pr
oxy34
96#ha
sConte
ntLeve
lPermi
ssion.
Canno
t
resolv
e
which
metho
d to
invoke
for
[null,
class
java.
lang.
String,
class
com.

atlassi
an.
conflu
ence.
pages.
Page]
due to
overla
pping
prototy
pes
betwe
en:
[interfa
ce
com.
atlassi
an.
conflu
ence.
user.
Conflu
enceU
ser,
class
java.
lang.
String,
class
com.
atlassi
an.
conflu
ence.
core.
Conte
ntEntit
yObjec
t]

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

Copyright Notice

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

Technology Licenses

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

Environmental Protection

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.

REACH, RoHS and WEEE

REACH

Trenz Electronic is a manufacturer and a distributor of electronic products. It is therefore a so called downstream user in the sense of [REACH](#). The products we supply to you are solely non-chemical products (goods). Moreover and under normal and reasonably foreseeable circumstances of application, the goods supplied to you shall not release any substance. For that, Trenz Electronic is obliged to neither register nor to provide safety data sheet. According to present knowledge and to best of our knowledge, no [SVHC \(Substances of Very High Concern\) on the Candidate List](#) are contained in our products. Furthermore, we will immediately and unsolicited inform our customers in compliance with REACH - Article 33 if any substance present in our goods (above a concentration of 0,1 % weight by weight) will be classified as SVHC by the [European Chemicals Agency \(ECHA\)](#).

RoHS

Trenz Electronic GmbH herewith declares that all its products are developed, manufactured and distributed RoHS compliant.

WEEE

Information for users within the European Union in accordance with Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

Users of electrical and electronic equipment in private households are required not to dispose of waste electrical and electronic equipment as unsorted municipal waste and to collect such waste electrical and electronic equipment separately. By the 13 August 2005, Member States shall have ensured that systems are set up allowing final holders and distributors to return waste electrical and electronic equipment at least free of charge. Member States shall ensure the availability and accessibility of the necessary collection facilities. Separate collection is the precondition to ensure specific treatment and recycling of waste electrical and electronic equipment and is necessary to achieve the chosen level of protection of human health and the environment in the European Union. Consumers have to actively contribute to the success of such collection and the return of waste electrical and electronic equipment. Presence of hazardous substances in electrical and electronic equipment results in potential effects on the environment and human health. The symbol consisting of the crossed-out wheeled bin indicates separate collection for waste electrical and electronic equipment.

Trenz Electronic is registered under WEEE-Reg.-Nr. DE97922676.

Ambiguous method overloading for method `jdk.proxy241.$Proxy3496#hasContentLevelPermission`. Cannot resolve which method to invoke for `[null, class java.lang.String, class com.atlassian.confluence.pages.Page]` due to overlapping prototypes between: `[interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]` `[interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]`