TEI0050 Test Board

Tebler of contents

Refer to Otype://ireanz.org/tei0050-info for the current online version of this manual and other available documentation. 1.1 Key Features

- 1.2 Revision History
 1.3 Release Notes and Know Issues

Key Features inements 1.4.1 Software 1.4.2 Hardware Quartus Bright Life 21.1.1 NIOS II 1.5.1 Design Sources

- UART
- UART 1.5.1 Design So
 UART 1.5.2 Prebuilt
 QSPI flash 1.5.3 Download
 2 SPRAM-memory
 3 User UFD
 User buttpprogramming

- - 3.1.1 Get prebuilt files
 - 3.1.2 QSPI

Revision HistoryTAG

○ 3.2 Usage

■ 3.2.1 UART			
Date4 System DesignoualHastus ○ 4.1 Block Design	Project Built	Authors	Description
2023-023-054-054-054-054-054-054-054-054-054-054	20230243145533.zip	Thomas Dück	fixed BSP_DIR in software project
2022-08-11 6.5 Linzitation.itef Liability 6.6 Copyright Notice 6.7 Technology Licenses 6.8 Environmental Protecti 6.9 REACH, RoHS and W 7 Table of contents	TEI0050- test_board_noprebui It-quartus_21.1.1- c20220811093744.zip EEE TEI0050-test_board- quartus_21.1.1- 20220811093807.zip	Thomas Dück	initial release

Design Revision History

Release Notes and Know Issues

Issues	Description	Workaround	To be fixed version
No known issues			

Known Issues

Requirements

Software

|--|

Quartus Prime Lite	21.1.1	needed
NIOS II SBT for Eclipse		optional

Software

Hardware

Complete List is available on ct folder>/board_files/*_board_files.csv

Design supports following modules:

Module Model	Board Part Short Name	PCB Revision Support	DDR	QSPI Flash	Others	Notes
TEI0050-01- AAH11A	AH11	REV01	8MByte	2MByte		
TEI0050-01- AAH13A*	AH13	REV01	8MByte	8MByte		

^{*}used as reference

Hardware Modules

Design supports following carriers:

Carrier Model	Notes

^{*}used as reference

Hardware Carrier

Additional HW Requirements:

Additional Hardware	Notes
USB cable for JTAG/UART	Check Carrier Board and Programmer for correct type

^{*}used as reference

Additional Hardware

Content

For general structure and usage of the reference design, see Project Delivery - Intel devices

Design Sources

Туре	Location	Notes
Quartus	<pre><pre><pre><pre><pre><pre><pre>/quartus</pre></pre></pre></pre></pre></pre></pre>	Quartus project will be generated by TE Scripts
Software	<pre><pre><pre><pre><pre><pre><pre>/software</pre></pre></pre></pre></pre></pre></pre>	Additional software will be generated by TE Scripts

Design sources

Prebuilt

File	File-Extension	Description
SOPC Information File	*.sopcinfo	File with description of the .qsys file to create software for the target hardware
SRAM Object File	*.sof	Ram configuration file
JTAG indirect configuration file	*.jic	Flash configuration file
Diverse Reports		Report files in different formats
Software-Application-File	*.elf	Software application for NIOS II processor system

Prebuilt files (only on ZIP with prebult content)

Download

Reference Design is only usable with the specified Quartus version. Do never use different versions of Quartus software for the same project.

Reference Design is available on:

TEI0050 "Test Board" Reference Design

Design Flow



Reference Design is available with and without prebuilt files. It's recommended to use TE prebuilt files for first launch.

Trenz Electronic provides a tcl based built environment based on Quartus Design Flow.


See also:

• Project Delivery - Intel devices

The Trenz Electronic FPGA Reference Designs are TCL-script based projects. To create a project, open a project or program a device execute "create_project_win.cmd" on Windows OS and "create_project_linux.sh" on Linux OS.

TE Scripts are only needed to generate the quartus project, all other additional steps are optional and can also executed by Intel Quartus/SDK GUI. For currently Scripts limitations on Win OS and Linux OS see: Project Delivery - Intel devices Currently limitations of functionality

1. Open create_project_win.cmd/create_project_linux.sh:



- 2. Select Board in "Board selection"
- 3. Click on "Create project" button to create project
 - a. (optional for manual changes) Select correct quartus installation path in "project folder>/settings/design_basic_settings.tcl"

Launch

Programming



Check Module and Carrier TRMs for proper HW configuration before you try any design.

Get prebuilt files



Reference Design is also available with prebuilt files. It's recommended to use TE prebuilt files for first launch.

- 1. Run create_project_win.cmd/create_project_linux.sh
- 2. Select Module in 'Board selection'
- 3. Click on 'Export prebuilt files' button
 - a. Folder roject folder/binaries_Article Name> with subfolder programming_files will be generated and opened

QSPI

- 1. Connect JTAG and power on carrier with module
- 2. Open create_project_win.cmd/create_project_linux.sh
- 3. Select correct board in "Board selection"
- 4. Click on "Program device" button
 - a. if prebuilt files are available: select "Program prebuilt file"

- b. using own generated programming file: select "Program other file" and click on "Browse ..." to open own generated programming file
- c. (optional) click on "Open programmer GUI" to program device with Quartus programmer GUI
- 5. Click on "Start program device" button

JTAG

Not used on this example.

Usage

- 1. Prepare HW like described on section Programming
- 2. Connect UART USB (most cases same as JTAG)

UART

- 1. Open Serial Console (e.g. PuTTY)
 - a. select COM Port




- b. Speed: 115200
- 2. Press reset button S1
- 3. Press user button S2 to toggle between different LED sequences
- 4. Console output depends on used Software project, see Software Design SDK#Application


System Design - Quartus

Block Design

The block designs may differ depending on the assembly variant.



Block Design - Project



Block Design - Platform Desginer

Software Design - SDK

Application

Used software project depends on board assembly variant. Template location: cource_files/software/

hello_tei0050

'hello_tei0050' is a Hello World example as endless loop instead of one console output.

Appx. A: Change History and Legal Notices

Document Change History

To get content of older revision got to "Change History" of this page and select older document revision number.

Date	Document Revision	Authors	Description
			fixed BSP_DIR in software project
Error	Error	Error	
renderi	renderi	renderi	
ng	ng	ng	
macro	macro	macro	
'page-	'page-	'page-	
info'	info'	info'	
Ambiguo	Ambiguo	Ambiguo	
us	us	us	
method	method	method	
overload	overload	overload	
ing for	ing for	ing for	
method	method	method	

proxy24 proxy24 proxy24 1.\$Proxy 1.\$Proxy 1.\$Proxy 3496#ha 3496#ha 3496#ha sConten sConten tLevelPe tLevelPe tLevelPe rmission rmission	
1.\$Proxy 1.\$Proxy 1.\$Proxy 3496#ha 3496#ha 3496#ha sConten sConten sConten tLevelPe tLevelPe tLevelPe rmission rmission rmission . . . Cannot Cannot Cannot	- 1
sConten tLevelPe tmission Cannot sConten	
tLevelPe tLevelPe tLevelPe rmission rmission	
rmission rmission rmission	
resolve resolve resolve	
which which which	
method method method	
to to to	
invoke invoke invoke	
for [null, for [null, for [null,	
class class class	
java. java. java.	
lang. lang. lang.	
String, String, String,	
class class class	
com. com. com.	
atlassian atlassian atlassian	
confluen confluen confluen	
ce. ce. ce.	
pages. pages. pages.	
Page] Page] Page]	
due to due to due to	
overlapp overlapp overlapp	
ing ing ing	
prototyp prototyp prototyp	
es es es	
between between between	
: :	
[interfac [interfac [interfac	
e com. e com. e com.	
atlassian atlassian atlassian	
confluen confluen confluen	

-	all		
022-08-11	v.5	Thomas Dück	inital release
ject]	ject]	ject]	
EntityOb	EntityOb	EntityOb	
Content	Content	Content	
ce.core.	ce.core.	ce.core.	
confluen	confluen	confluen	
•		·	
atlassian	atlassian	atlassian	
com.	com.	com.	
class	class	class	
String,	String,	String,	
lang.	lang.	lang.	
java.	java.	java.	
class	class	class	
User,	User,	User,	
.user.	.user.	.user.	
atlassian	atlassian	atlassian	
e com.	e com.	e com.	
[interfac	[interfac	[interfac	
ject]	ject]	ject]	
EntityOb ioct1	EntityOb	EntityOb	
Ce.core.	Ce.core.	Ce.core.	
ce.core.	ce.core.	ce.core.	
confluen	confluen	confluen	
aliassiai i	สแสจจเสเ	aliassiai i	
com. atlassian	com. atlassian	com. atlassian	
String, class	String, class	class	
lang.	lang.	lang. String,	
java.	java.	java.	
, class	, class	, class	
nceUser	nceUser		
Conflue		nceUser	
Canffina	Conflue	Conflue	

Error

renderi

ng

macro

'page-

info'

Ambiguo

us

method

overload

ing for

method

ilictiloa

jdk.

proxy24

1.\$Proxy

3496#ha

sConten

tLevelPe

rmission

.

Cannot

resolve

which

method

to

invoke

for [null,

class

java.

lang.

String,

class

com.

atlassian

.


confluen

ce.

pages.

Page]

due to overlapp ing prototyp es between [interfac e com. atlassian confluen ce.user. Conflue nceUser , class java. lang. String, class com. atlassian confluen ce.core. Content EntityOb ject] [interfac e com. atlassian .user. User, class java. lang. String, class com.



Document change history

Legal Notices

Data Privacy

Please also note our data protection declaration at https://www.trenz-electronic.de/en/Data-protection-Privacy

Document Warranty

The material contained in this document is provided "as is" and is subject to being changed at any time without notice. Trenz Electronic does not warrant the accuracy and completeness of the materials in this document. Further, to the maximum extent permitted by applicable law, Trenz Electronic disclaims all warranties, either express or implied, with regard to this document and any information contained herein, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non infringement of intellectual property. Trenz Electronic shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein.

Limitation of Liability

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

Copyright Notice

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

Technology Licenses

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

Environmental Protection

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.

REACH, RoHS and WEEE

REACH

Trenz Electronic is a manufacturer and a distributor of electronic products. It is therefore a so called downstream user in the sense of REACH. The products we supply to you are solely non-chemical products (goods). Moreover and under normal and reasonably foreseeable circumstances of application, the goods supplied to you shall not release any substance. For that, Trenz Electronic is obliged to neither register nor to provide safety data sheet. According to present knowledge and to best of our knowledge, no SVHC (Substances of Very High Concern) on the Candidate List are contained in our products. Furthermore, we will immediately and unsolicited inform our customers in compliance with REACH - Article 33 if any substance present in our goods (above a concentration of 0,1 % weight by weight) will be classified as SVHC by the European Chemicals Agency (ECHA).

RoHS

Trenz Electronic GmbH herewith declares that all its products are developed, manufactured and distributed RoHS compliant.

WEEE

Information for users within the European Union in accordance with Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

Users of electrical and electronic equipment in private households are required not to dispose of waste electrical and electronic equipment as unsorted municipal waste and to collect such waste electrical and electronic equipment separately. By the 13 August 2005, Member States shall have ensured that systems are set up allowing final holders and distributors to return waste electrical and electronic equipment at least free of charge. Member States shall ensure the availability and accessibility of the necessary collection facilities. Separate collection is the precondition to ensure specific treatment and recycling of waste electrical and electronic equipment and is necessary to achieve the chosen level of protection of human health and the environment in the European Union. Consumers have to actively contribute to the success of such collection and the return of waste electrical and electronic equipment. Presence of hazardous substances in electrical and electronic equipment results in potential effects on the environment and human health. The symbol consisting of the crossed-out wheeled bin indicates separate collection for waste electrical and electronic equipment.

Trenz Electronic is registered under WEEE-Reg.-Nr. DE97922676.

Error rendering macro 'page-info'

Ambiguous method overloading for method jdk.

proxy241.\$Proxy3496#hasContentLevelPermission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.

 $Confluence User, \ class \ java.lang. String, \ class \ com. at lassian. confluence. core.$

ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]