

DEWEsoft C++ DLL to Trenz Electronic C++ DLL

Introduction

How to write C++ programs using the new DLL starting from the old DLL.

There are some major differences between the two DLLs.

feature	Dewesoft C++ DLL	Trenz Electronic C++ DLL
programming language	C++	C++
architecture	standard (TE0300DLL.dll)	stacked (TE_USB_FX2_CyAPI.dll requires Cypress CyAPI.dll);
Handles	present	absent
structures	embedded	defined in Cypress CyAPI.h
parameters*	less	more
freedom*	less	more
buffer size	2 Kbyte (fixed)	4 Kbyte or more (it can be changed)

Feature of Dewesoft C++ DLL and Trenz Electronic C++ DLL

Function translation

Dewesoft C++ DLL	Trenz Electronic C++ DLL
HANDLE m_handle = 0;	<pre>CCyUSBDevice *USBdevList = new CCyUSBDevice((HANDLE)0,CYUSBDRV_GUID,true);</pre> <p> The handles are internally managed by CyAPI.lib and there is no need to expose them to the user.</p> <p> CyUSBDevice TE_USB_FX2_USBDevice doesn't explicitly exist in C++, unlike the C# case; this is a shortcoming of CyAPI.lib. d=0; USBdevList->Open(d); // Open automatically calls Close() if necessary vID = USBdevList->VendorID; // not (USBdevList->TE_USB_FX2_USBDevice).VendorID as logically expected pID = USBdevList->ProductID; // not (USBdevList->TE_USB_FX2_USBDevice).ProductID as logically expected</p>
<pre>cout << endl << TE0300_ScanCards() << endl;</pre>	<pre>cout << endl << TE_USB_FX2_ScanCards(USBdevList) << endl;</pre>

TE0300_Open (&m_handle, 0)!=0;	<p>TE_USB_FX2_Open(USBdevList, 0)!=0;</p> <p> TE_USB_FX2_Open()</p> <p>In the code, it is possible to call TE_USB_FX2_Open() where TE0300_Open() is used.</p>
	<p> TE_USB_FX2_Open() act as Close() for other TE USB handles already open</p> <p>When a new handle to the device driver is open (TE_USB_FX2_Open() run successfully) other internal handles (inside USBDeviceList) are automatically closed by TE_USB_FX2_Open() function. No more than one handle can be active on the same time. It is a behavior inherited by CyAPI.dll Open() function. For this reason, TE_USB_FX2_Close() function is almost useless.</p> <p>d=0; USBdevList->Open(d); // Open automatically calls Close() if necessary (from the Cypress CyAPI documentation)</p>
	<p> TE_USB_FX2_Open() as SelectCard()</p> <p>TE_USB_FX2_Open(USBdevList, x) acts more as a SelectCard() function because the list of USB devices is already created in USBdevList.</p>
TE0300_Open (&m_handle, 1)!=0;	TE_USB_FX2_Open(USBdevList, 1)!=0
TE0300_Close (&m_handle);	<p>TE_USB_FX2_Close(USBdevList);</p> <p> This function closes all internal handles of USBDeviceList.</p> <p>This function does NOT differ much from its homonym of the previous TE0300DLL.dll; the only difference is that this function closes a handle (like TE0300DLL.dll) to the driver but the handle is not exposed to user because it is not exposed by USBDeviceList (unlike TE0300DLL.dll).</p> <p>In the code, it is possible to call TE_USB_FX2_Close() where TE0300_Close() is used, but</p> <ul style="list-style-type: none"> • it is rare that you would ever need to call TE_USB_FX2_Close() explicitly (though doing so would not cause any problems). • TE_USB_FX2_Open() realize automatically much of the TE_USB_FX2_Close() work. Close is automatically carried out by the TE_USB_FX2_Open() function, if another handle to the same device driver is already open (i.e. a TE_USB_FX2_Open() has been successfully used before).
	<p> Warning about derived variables</p> <p>If TE_USB_FX2_Close() is called, then dynamically allocated members of the CCyUSBDevice class are deallocated. And, all "shortcut" pointers to elements of the EndPoints array (ControlEndPt, IsocIn/OutEndPt, BulkIn/OutEndPt, InterruptIn/OutEndPt) are reset to NULL.</p>
TE0300_SendCommand (handle, cmd, cmd_length, reply, &reply_length, timeout)	TE_USB_FX2_SendCommand(USBdevList, cmd, cmd_length, reply, reply_length, timeout)

Equivalent code doesn't exist	<pre>TE_USB_FX2_SetData_InstanceDriverBuffer (USBdevList, &BulkOutEP, PI_EP8, timeout, DeviceDriverBufferSize);</pre> <p> Example: in TE0300DLL.dll, the SET buffer size is fixed to 2 Kbyte, while in TE_USB_FX2_CyAPI.dll you are free to choose 4 Kbyte or more.</p> <p>BufferSize has a strong influence on DataThroughput. If BufferSize is too small, the data throughput can be 1/3 to 1/2 of the maximum value (33-36 Mbyte/s for read transactions).</p> <p>You should instance the driver buffer only one time and not for every transmission, otherwise you could half your data throughput.</p>
Equivalent code doesn't exist	<pre>TE_USB_FX2_GetData_InstanceDriverBuffer (USBdevList, &BulkInEP, PI_EP6, timeout, DeviceDriverBufferSize);</pre> <p> Example: in TE0300DLL.dll, the GET buffer size is fixed to 2 Kbyte, while in TE_USB_FX2_CyAPI.dll you are free to choose 4 Kbyte or more.</p> <p>BufferSize has a strong influence on DataThroughput. If BufferSize is too small, the DataThroughput can be 1/3 to 1/2 of the maximum value (25-28 Mbyte/s for write transactions).</p> <p>You should instance the driver buffer only one time and not for every transmission, otherwise you could half your data throughput.</p>

Function Translation from DEWESoft C++ to Trenz Electronic C++

Examples

Dewesoft C++ DLL	Trenz Electronic C++ DLL
<pre>//test code, not production code int packetlen = 512; byte data[512];</pre>	<pre>//test code, not production code int packetlen = 512; byte data[512];</pre>
	<pre>CCyBulkEndPoint *BulkOutEP = NULL; TE_USB_FX2_SetData_InstanceDriverBuffer (USBdevList, &BulkOutEP, PI_EP8, timeout, DeviceDriverBufferSize);</pre>
<pre>for (int i = 0; i < 10; i++) { packetlen = 512; for (int j = 0; j < packetlen; j++) data[j] = j; if (TE0300_SetData(handle, data, packetlen, PI_EP8)) { cout << "ERROR" << endl; return; } }</pre>	<pre>for (int i = 0; i < 10; i++) { packetlen = 512; for (int j = 0; j < packetlen; j++) data[j] = j; if (TE_USB_FX2_SetData(&BulkOutEP, data, packetlen)) { cout << "ERROR" << endl; return; } }</pre>

Simplified Example 1

Dewesoft C++ DLL	Trenz Electronic C++ DLL
<pre>int packetlen = 512; byte data[512];</pre>	<pre>int packetlen = 512; byte data[512];</pre>

	<pre> CCyBulkEndPoint *BulkInEP = NULL; TE_USB_FX2_GetData_InstanceDriverBuffer (USBdevList, &BulkInEP, PI_EP6, timeout, DeviceDriverBufferSize); for (int i = 0; i < 10; i++) { packetlen = 512; if (TE0300_GetData(handle, data, &packetlen, PI_EP6, 1000)) { cout << "ERROR" << endl; return; } for (int j = 0; j < packetlen; j++) cout << data[j]; cout << endl; } </pre>
Simplified Example 2	<pre> for (int i = 0; i < 10; i++) { packetlen = 512; if (TE_USB_FX2_GetData(&BulkInEP, data, packetlen)) { cout << "ERROR" << endl; return; } for (int j = 0; j < packetlen; j++) cout << data[j]; cout << endl; } </pre>

Simplified Example 2

Dewesoft C++ DLL	Trenz Electronic C++ DLL
<pre>void ReadData(unsigned int handle) {</pre>	<pre>void ReadData (CCyUSBDevice *USBdevList, unsigned int DeviceDriverBufferSize, int RX_PACKET_LEN, unsigned long TIMEOUT) {</pre>
<pre> int packetlen = RX_PACKET_LEN; unsigned int packets = 1200; //allocate memory byte * data; data = new byte [RX_PACKET_LEN*packets];</pre>	<pre> long packetlen = RX_PACKET_LEN; unsigned int packets = 1200; //allocate memory byte * data; byte * data_temp = NULL; data = new byte [RX_PACKET_LEN*packets];</pre>
<pre> unsigned int total_cnt = 0; unsigned int errors = 0;</pre>	<pre> unsigned int total_cnt = 0; unsigned int errors = 0;</pre>
	<pre> //Instantiate driver buffer CCyBulkEndPoint *BulkInEP = NULL; TE_USB_FX2_GetData_InstanceDriverBuffer (USBdevList, CardNo, &BulkInEP, PI_EP6, TIMEOUT, DeviceDriverBufferSize);</pre>
<pre> //starts test ResetFX2FifoStatus(handle); SendFPGACommand(handle, FX22MB_REG0_START_TX);</pre>	<pre> //starts test ResetFX2FifoStatus(USBdevList); SendFPGACommand(USBdevList, FX22MB_REG0_START_TX);</pre>
<pre> //StopWatch starts ElapsedTime.Start(); for (unsigned int i = 0; i < packets; i++) { packetlen = RX_PACKET_LEN;</pre>	<pre> //StopWatch starts ElapsedTime.Start(); for (unsigned int i = 0; i < packets; i++) { packetlen = RX_PACKET_LEN;</pre>
	<pre> data_temp = &data[total_cnt];</pre>

<pre> if (TE0300_GetData(handle, data+total_cnt, &packetlen, PI_EP6,TIMEOUT_MS)) { cout << "ERROR read" << endl; errors++; break; } total_cnt += packetlen; } TheElapsedTime = ElapsedTime.Stop(false); //DEBUG StopWatch timer SendFPGACmd(USBDevice, FX22MB_REG0_STOP); //stops test delete data; } </pre>	<pre> if (TE_USB_FX2_GetData(&BulkInEP,data_temp, packetlen)) { cout << "ERROR read" << endl; errors++; break; } total_cnt += (packetlen); } TheElapsedTime = ElapsedTime.Stop(false); //DEBUG StopWatch timer SendFPGACmd(USBDevice, FX22MB_REG0_STOP); //stops test delete data; } </pre>
--	---

Read Data Test Example

Dewesoft C++ DLL	Trenz Electronic C++ DLL
<code>void WriteData(unsigned int handle)</code> { <code>int packetlen = TX_PACKET_LEN;</code> <code>unsigned int packets = 1200;</code> <code>//allocate memory</code> <code>byte * data;</code> <code>data = new byte [TX_PACKET_LEN*packets];</code> <code>unsigned int total_cnt = 0;</code> <code>unsigned int errors = 0;</code> <code>CCyBulkEndPoint *BulkOutEP = NULL;</code> <code>TE_USB_FX2_SetData_InstanceDriverBuffer</code> <code>(USBDevList, CardNo, &BulkOutEP, PI_EP8,TIMEOUT,</code> <code>DeviceDriverBufferSize);</code> <code>SetData (data);</code> <code>ResetFX2FifoStatus(handle);</code> <code>//starts test</code> <code>SendFPGACmd(handle,</code> <code>FX22MB_REG0_START_RX);</code> <code>//StopWatch starts</code> <code>ElapsedTime.Start();</code> <code>for (unsigned int i = 0; i < packets; i++)</code> { <code>packetlen = RX_PACKET_LEN;</code> <code>data_temp = &data[total_cnt];</code>	<code>void WriteData(CCyUSBDevice *USBdevList,</code> <code>unsigned int DeviceDriverBufferSize,</code> <code>int TX_PACKET_LEN, unsigned long TIMEOUT)</code> { <code>long packetlen = TX_PACKET_LEN;</code> <code>unsigned int packets = 1200;</code> <code>//allocate memory</code> <code>byte * data;</code> <code>byte * data_temp = NULL;</code> <code>data = new byte [TX_PACKET_LEN*packets];</code> <code>unsigned int total_cnt = 0;</code> <code>unsigned int errors = 0;</code> <code>CCyBulkEndPoint *BulkOutEP = NULL;</code> <code>TE_USB_FX2_SetData_InstanceDriverBuffer</code> <code>(USBDevList, CardNo, &BulkOutEP, PI_EP8,TIMEOUT,</code> <code>DeviceDriverBufferSize);</code> <code>SetData (data);</code> <code>ResetFX2FifoStatus(USBdevList);</code> <code>//starts test</code> <code>SendFPGACmd(USBdevList,</code> <code>FX22MB_REG0_START_RX);</code> <code>//StopWatch starts</code> <code>ElapsedTime.Start();</code> <code>for (unsigned int i = 0; i < packets; i++)</code> { <code>packetlen = RX_PACKET_LEN;</code> <code>data_temp = &data[total_cnt];</code>

```

if (TE0300_SetData(handle, data+total_cnt,
&packetlen, PI_EP8,TIMEOUT_MS))
{
    cout << "ERROR write" << endl;
    errors++;
    break;
}
total_cnt += packetlen;
}
TheElapsedTime = ElapsedTime.Stop(false);
//DEBUG StopWatch timer
SendFPGACommand(USBDevice,
FX22MB_REG0_STOP);
//stops test
delete data;
}

if (TE_USB_FX2_SetData(&BulkOutEP,data_temp,
packetlen))
{
    cout << "ERROR write" << endl;
    errors++;
    break;
}
total_cnt += (packetlen);
}
TheElapsedTime = ElapsedTime.Stop(false);
//DEBUG StopWatch timer
SendFPGACommand(USBDevice,
FX22MB_REG0_STOP);
//stops test
delete data;
}

```

Write Data Test Example