

TEB0911 Master CPLD

Table of contents

- 1 [Table of contents](#)
- 2 [Overview](#)
 - 2.1 [Feature Summary](#)
 - 2.2 [Firmware Revision and supported PCB Revision](#)
- 3 [Product Specification](#)
 - 3.1 [Port Description](#)
 - 3.2 [Functional Description](#)
 - 3.2.1 [JTAG](#)
 - 3.2.2 [Power](#)
 - 3.2.3 [Reset](#)
 - 3.2.4 [Bootmode](#)
 - 3.2.5 [FANs](#)
 - 3.2.6 [RGPIO](#)
- 4 [Appx. A: Change History](#)
 - 4.1 [Revision Changes](#)
 - 4.2 [Document Change History](#)
- 5 [Appx. B: Legal Notices](#)
 - 5.1 [Data Privacy](#)
 - 5.2 [Document Warranty](#)
 - 5.3 [Limitation of Liability](#)
 - 5.4 [Copyright Notice](#)
 - 5.5 [Technology Licenses](#)
 - 5.6 [Environmental Protection](#)
 - 5.7 [REACH, RoHS and WEEE](#)

Overview

Firmware for PCB-Master CPLD with designator U27:LCMXO2-1200HC

Feature Summary

- Power Management
- Reset Management
- FMC JTAG Management
- FPGA Boot Mode
- RGPIO Interface to FPGA

Firmware Revision and supported PCB Revision

See Document Change History

Product Specification

Port Description

Name/ opt. VHD Name	Direction	Pin	Description
B64_T1	out	20	FPGA IO / Master RGPIO TX

B64_T2	in	19	FPGA IO / Master RGPIO RX
B64_T3	in	21	FPGA IO / Master RGPIO CLK
B65_T1	out	22	FPGA IO / Slave RGPIO TX
B65_T2	in	24	FPGA IO / Slave RGPIO RX
B65_T3	in	23	FPGA IO / Slave RGPIO CLK
C_TCK	in	131	JTAG
C_TDI	in	136	JTAG
C_TDO1	out	137	JTAG
C_TMS	in	130	JTAG
DDR_EN/EN_DDR	out	126	Power control
DDR_PG		121	Power control / <i>currently_not_used</i>
DONE	in	4	FPGA Control
DP_EN	out	34	Power control
EN_12V	out	114	Power control
EN_3.3V	out	112	Power control
EN_A_3V3	out	143	Power control
EN_AF_1V8	out	110	Power control
EN_B_3V3	out	74	Power control
EN_BC_1V8	out	84	Power control
EN_C_3V3	out	76	Power control
EN_D_3V3	out	78	Power control
EN_DE_1V8	out	77	Power control
EN_E_3V3	out	82	Power control
EN_F_3V3	out	104	Power control
EN_GT_L	out	122	Power control
EN_GT_R	out	125	Power control
EN_SFP	out	111	Power control
EN_SFP_SSD	out	3	Power control
EN_VCCINT	out	119	Power control
FAN_A_EN	out	106	Fan control
FAN_B_EN	out	83	Fan control
FAN_C_EN	out	81	Fan control
FAN_D_EN	out	75	Fan control
FAN_E_EN	out	73	Fan control
FAN_F_EN	out	109	Fan control
FMC12V_EN/EN_FMC_12V	out	95	Power control
FMC12V_PG		93	Power control / <i>currently_not_used</i>
FMCA_PG_C2M		142	Power control / <i>currently_not_used</i>
FMCA_PG_M2C		141	Power control / <i>currently_not_used</i>
FMCA_PRSENT	in	140	FMC

FMCA_TCK	out	139	FMC / JTAG
FMCA_TDI	out	138	FMC / JTAG
FMCA_TDO	in	133	FMC / JTAG
FMCA_TMS	out	132	FMC / JTAG
FMCB_PG_C2M		38	FMC / <i>currently_not_used</i>
FMCB_PG_M2C		39	<i>FMC / currently_not_used</i>
FMCB_PRSNT	in	40	FMC
FMCB_TCK	out	41	FMC / JTAG
FMCB_TDI	out	42	FMC / JTAG
FMCB_TDO	in	43	FMC / JTAG
FMCB_TMS	out	44	FMC / JTAG
FMCC_PG_C2M		54	FMC / <i>currently_not_used</i>
FMCC_PG_M2C		55	FMC / <i>currently_not_used</i>
FMCC_PRSNT	in	56	FMC
FMCC_TCK	out	57	FMC / JTAG
FMCC_TDI	out	58	FMC / JTAG
FMCC_TDO	in	59	FMC / JTAG
FMCC_TMS	out	60	FMC / JTAG
FMCD_PG_C2M		45	FMC / <i>currently_not_used</i>
FMCD_PG_M2C		47	FMC / <i>currently_not_used</i>
FMCD_PRSNT	in	61	FMC
FMCD_TCK	out	48	FMC / JTAG
FMCD_TDI	out	49	FMC / JTAG
FMCD_TDO	in	50	FMC / JTAG
FMCD_TMS	out	52	FMC / JTAG
FMCE_PG_C2M		62	FMC / <i>currently_not_used</i>
FMCE_PG_M2C		65	FMC / <i>currently_not_used</i>
FMCE_PRSNT	in	67	FMC
FMCE_TCK	out	68	FMC / JTAG
FMCE_TDI	out	69	FMC / JTAG
FMCE_TDO	in	70	FMC / JTAG
FMCE_TMS	out	71	FMC / JTAG
FMTF_PG_C2M		107	FMC / <i>currently_not_used</i>
FMTF_PG_M2C		105	FMC / <i>currently_not_used</i>
FMTF_PRSNT	in	100	FMC
FMTF_TCK	out	99	FMC / JTAG
FMTF_TDI	out	98	FMC / JTAG
FMTF_TDO	in	97	FMC / JTAG
FMTF_TMS	out	96	FMC / JTAG
INIT_B	in	5	FPGA Control

JTAGENB	--	120	enable JTAG access to CPLD (one CPLD, zero FMC chain)
MIO24		1	FGPA MIO / currently_not_used
MIO25		2	FGPA MIO / currently_not_used
MODE0	out	10	FPGA Boot Mode
MODE1	out	12	FPGA Boot Mode
MODE2	out	9	FPGA Boot Mode
MODE3	out	11	FPGA Boot Mode
MR	out	92	FPGA Control
PG_12V	in	113	Power control
PG_FPD	in	115	Power control
PG_GT_L	in	13	Power control
PG_GT_R	in	35	Power control
PG_PSGT	in	128	Power control
PROG_B	out	6	FPGA Control
PSGT_EN/EN_GT_PS	out	117	Power control
SC_IO0	out	25	Slave CPLD / Reset
SC_IO1		26	Slave CPLD / currently_not_used
SC_IO2		27	Slave CPLD / currently_not_used
SC_IO3	in	28	Slave CPLD / Slave RGPIO TX_IN
SC_IO4	out	32	Slave CPLD / Slave RGPIO RX_OUT
SC_IO5	out	33	Slave CPLD / Slave RGPIO CLK_out
SC_SW1	in	127	DIP Switch S3-3
SC_SW2	in	85	DIP Switch S3-4
SC1_IO_SB		91	Slave CPLD / currently_not_used
SC2_IO_SB		86	Slave CPLD / currently_not_used
USR_BUT2	in	94	Button / Global Reset

Functional Description

JTAG

JTAGENB set CPLD into the Chain for Firmware update. In normal mode every FMC JTAG will be set into the chain, when his FMCx_PRSENT is detected.

Power

EN_12V and EN_VCCINT are enabled on power up. All other power enables will be set, if PG_12V and PG_FPD are valid.

Reset

PROG_B always one. MR and SC_IO0 controlled by USR_BUT2 (S2) and power management.

Bootmode

SD Boot, when SC_SW1 is one else SQPI Boot.

S4-3	S4-5	Description
OFF	OFF	SD1 Boot
OFF	ON	PJTAG0
ON	OFF	QSPI32
ON	ON	JTAG

FANs

6 FMC FANs controlled by corresponding FMCx_PRSENT signals to enable FANs only for active FMC slots.

RGPIO

RGPIO Master is a 32Bit Remote GPIO Interface to talk with FPGA over 3 lanes.

RGPIO Pin to FPGA	Value
0-3	current Boot Mode
4	SC_SW1
5	SC_SW2
6-7	unused
8-13	FMCA...F_PRSENT
14-19	unused
20	PG_PSGT
21	PG_GT_L
22	PG_GT_R
23	unused
24-27	reserved
28-31	interface detection

RGPIO Pin from FPGA	Value
0-23	unused
24-27	reserved
28-31	interface detection

RGPIO slave is routed directly to Slave CPLD.

Appx. A: Change History


Revision Changes

CPLD REV04 to REV05

- more Boot Modes selectable
- Power startup sequence

Document Change History

To get content of older revision got to "Change History" of this page and select older document revision number.

Date	Document Revision	CPLD Firmware Revision	Supported PCB Revision	Authors	Description
	<div><div>Error rendering macro 'page-info'</div><div>Ambiguous method overloading for method jdk. proxy279.\$Proxy4022#hasContentLevel Permission. Cannot resolve which method to invoke for [null, class java.lang.String, class com.atlassian.confluence.pages.Page] due to overlapping prototypes between: [interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject] [interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]</div><div> Unknown macro: 'metadata'</div></div>	REV02	REV01	<div><div>Error rendering macro 'page-info'</div><div>Ambiguous method overloading for method jdk. proxy279.\$Proxy4022#hasContentLevel Permission. Cannot</div></div>	document style update

**Error rendering macro
'page-info'**

Ambiguous method
overloading for method
jdk.
proxy279.\$Proxy4022#h
asContentLevelPermissi
on. Cannot resolve
which method to invoke
for [null, class java.lang.
String, class com.
atlassian.confluence.
pages.Page] due to
overlapping prototypes
between: [interface com.
atlassian.confluence.
user.ConfluenceUser,
class java.lang.String,
class com.atlassian.
confluence.core.
ContentEntityObject]
[interface com.atlassian.
user.User, class java.
lang.String, class com.
atlassian.confluence.
core.
ContentEntityObject]

resolve
which
metho
d to
invoke
for
[null,
class
java.
lang.
String,
class
com.
atlassi
an.
conflue
nce.
pages.
Page]
due to
overlap
ping
prototy
pes
betwee
n:
[interfa
ce
com.
atlassi
an.
conflue
nce.
user.
Conflu
enceU
ser,
class
java.

				<div>lang. String, class com. atlassi an. conflue nce. core. Conten tEntity Object] [interfa ce com. atlassi an. user. User, class java. lang. String, class com. atlassi an. conflue nce. core. Conten tEntity Object]</div>	
2017-05-24	v.26	REV02	REV01	John Hartfiel	Revision 02 finished
2016-10-16	v.22	REV01	REV01	Oleksandr Kiyenko	Revision 01 finished
2016-04-11	v.1	---		<div></div>	Initial release

Error
render
ing
macro
'page-
info'

Ambig
uous
metho
d
overloa
ding
for
metho
d jdk.
proxy2
79.\$Pr
oxy402
2#has
Conten
tLevel
Permis
sion.
Cannot
resolve
which
metho
d to
invoke
for
[null,
class
java.
lang.
String,
class
com.
atlassi
an.

confluence.
pages.
Page]
due to
overlap
ping
prototypes
between:
[interface
com.
atlassian.
confluence.
user.
ConfluenceUser,
class
java.
lang.
String,
class
com.
atlassian.
confluence.
core.
ContentEntity
Object]
[interface
com.

				<div>atlassi an. user. User, class java. lang. String, class com. atlassi an. conflue nce. core. Conten tEntity Object]</div>	
	All			<div>Error render ing macro 'page- info' Ambig uous metho d overloa ding for metho d jdk. proxy2 79.\$Pr</div>	

oxy402
2#has
Conten
tLevel
Permis
sion.
Cannot
resolve
which
metho
d to
invoke
for
[null,
class
java.
lang.
String,
class
com.
atlassi
an.
conflue
nce.
pages.
Page]
due to
overlap
ping
prototy
pes
betwee
n:
[interfa
ce
com.
atlassi
an.
conflue

nce.
user.
Conflu
enceU
ser,
class
java.
lang.
String,
class
com.
atlassi
an.
conflue
nce.
core.
Conten
tEntity
Object]
[interfa
ce
com.
atlassi
an.
user.
User,
class
java.
lang.
String,
class
com.
atlassi
an.
conflue
nce.
core.
Conten
tEntity

Appx. B: Legal Notices

Data Privacy

Please also note our data protection declaration at <https://www.trenz-electronic.de/en/Data-protection-Privacy>

Document Warranty

The material contained in this document is provided “as is” and is subject to being changed at any time without notice. Trenz Electronic does not warrant the accuracy and completeness of the materials in this document. Further, to the maximum extent permitted by applicable law, Trenz Electronic disclaims all warranties, either express or implied, with regard to this document and any information contained herein, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non infringement of intellectual property. Trenz Electronic shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein.

Limitation of Liability

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

Copyright Notice

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

Technology Licenses

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

Environmental Protection

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.

REACH, RoHS and WEEE

REACH

Trenz Electronic is a manufacturer and a distributor of electronic products. It is therefore a so called downstream user in the sense of [REACH](#). The products we supply to you are solely non-chemical products (goods). Moreover and under normal and reasonably foreseeable circumstances of application, the goods supplied to you shall not release any substance. For that, Trenz Electronic is obliged to neither register nor to provide safety data sheet. According to present knowledge and to best of our knowledge, no [SVHC \(Substances of Very High Concern\) on the Candidate List](#) are contained in our products. Furthermore, we will immediately and unsolicited inform our customers in compliance with REACH - Article 33 if any substance present in our goods (above a concentration of 0,1 % weight by weight) will be classified as SVHC by the [European Chemicals Agency \(ECHA\)](#).

RoHS

Trenz Electronic GmbH herewith declares that all its products are developed, manufactured and distributed RoHS compliant.

WEEE

Information for users within the European Union in accordance with Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

Users of electrical and electronic equipment in private households are required not to dispose of waste electrical and electronic equipment as unsorted municipal waste and to collect such waste electrical and electronic equipment separately. By the 13 August 2005, Member States shall have ensured that systems are set up allowing final holders and distributors to return waste electrical and electronic equipment at least free of charge. Member States shall ensure the availability and accessibility of the necessary collection facilities. Separate collection is the precondition to ensure specific treatment and recycling of waste electrical and electronic equipment and is necessary to achieve the chosen level of protection of human health and the environment in the European Union. Consumers have to actively contribute to the success of such collection and the return of waste electrical and electronic equipment. Presence of hazardous substances in electrical and electronic equipment results in potential effects on the environment and human health. The symbol consisting of the crossed-out wheeled bin indicates separate collection for waste electrical and electronic equipment.

Trenz Electronic is registered under WEEE-Reg.-Nr. DE97922676.

Error rendering macro 'page-info'

Ambiguous method overloading for method `jdk.proxy279.$Proxy4022#hasContentLevelPermission`. Cannot resolve which method to invoke for `[null, class java.lang.String, class com.atlassian.confluence.pages.Page]` due to overlapping prototypes between: `[interface com.atlassian.confluence.user.ConfluenceUser, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]` `[interface com.atlassian.user.User, class java.lang.String, class com.atlassian.confluence.core.ContentEntityObject]`